



Operation for Setting Calendar and Alarmd snooze

DOWN UP SET MODE

Date and Time setting:

1. Under normal mode, press SET key enter date and time setting mode, press SET again to enter the next setting, the sequence of setting as below: Hour-minute-year-month-day-back;
2. Press UP and DOWN setting, the day of week will vary accordingly.
3. Under setting mode, Press MODE or no operation in 60 seconds will back from set mode, and display the time.
4. Under normal mode, press UP transfer 12 and 24 hours format.

Snooze function setting:

1. Under normal mode, press MODE enter alarm mode.
2. Under alarm mode, press SET enter alarm setting, press SET again enter the next setting, the sequence of setting as below: Hour-minute-year-month-day-back
3. Press UP and DOWN key to set.
4. Under alarm mode, press UP and DOWN key can open and close the snooze and alarm, press it again enter the next function, the sequence as below: Open the alarm-open the snooze-close alarm and snooze.
5. When reach the alarm, the alarm will last 1 minute, snooze time reach, alarm will ring again, press SET key it any button can stop the alarm.

